



Acer Iconia One 8 Battery Replacement

This repair guide will show you how to replace the battery in your Acer Iconia One 8 B1-850.

Written By: Josh Cooper




INTRODUCTION

This repair guide will show you how to replace the battery in your Acer Iconia One 8 B1-850.

TOOLS:

- [iFixit Opening Tools](#) (1)
-

Step 1 — Battery




- To remove the back panel, insert an opening tool into the small crack between the screen and back panel. Gently pry open the tablet.

Step 2




- Remove the black piece of tape that is holding the red, yellow, and white wires in place.

Step 3



- Once the tape has been removed, gently pinch the wires and remove them from the socket. They should come out easily.

Step 4



- Carefully work a plastic spudger underneath the battery and pry it free.
- ⓘ Use an iOpener or carefully apply heat with a heat gun to soften the adhesive under the battery.
- ⚠ Be careful not to bend or puncture the battery.

To reassemble your device, follow these instructions in reverse order.